



## Guide de configuration et d'activation d'un modem iDirect IQ

Ouvrir la page web sur 192.168.0.1	
User Name: admin Password: iDirect	
Sélectionner "Commissioning Wizard" depuis le menu déroulant	
Vérifier le Modem Serial Number pour s'assurer qu'il n'y a pas eu d'erreur dans le numéro de série indiqué à DSD	
Sélectionner "Enter Commissioning Mode"	



## Guide de configuration et d'activation d'un modem iDirect IQ

<p>Charger le logiciel Velocity Software <b>2.0.1.2</b> Si vous ne l'avez pas sur votre PC, vous le trouverez sur notre site web : <a href="#">Télécharger ici</a></p>	<p>Manage Software Packages</p> <table border="1"><thead><tr><th>Software</th><th>Package Name</th><th>Creation Date</th><th>Version</th><th>Action</th></tr></thead><tbody><tr><td>active1</td><td>Evolution Remote</td><td>03/13/2018</td><td>21.0.0.4-44</td><td>Activate Software Package</td></tr><tr><td>active0</td><td>Velocity Remote</td><td>03/13/2018</td><td>21.0.0.4-44</td><td>Activate Software Package</td></tr><tr><td>factory</td><td>Evolution Remote</td><td>03/13/2018</td><td>21.0.0.4-44</td><td>Software package is currently active</td></tr></tbody></table> <p>Configuration Files</p> <p>Manage Software Packages</p> <table border="1"><thead><tr><th>Partition</th><th>Type</th><th>Description</th><th>Version</th><th>Action</th></tr></thead><tbody><tr><td>active1</td><td>Evolution Remote</td><td>iDirect Remote Terminal Application</td><td>21.0.0.4-44</td><td>Activate Software Package</td></tr><tr><td>active0</td><td>Velocity Remote</td><td>iDirect Remote Terminal Application</td><td>2.0.0.1-3477</td><td>Activate Software Package</td></tr><tr><td>factory</td><td>Evolution Remote</td><td>iDirect Remote Terminal Application</td><td>21.0.0.4-44</td><td>Software package is currently active</td></tr></tbody></table>	Software	Package Name	Creation Date	Version	Action	active1	Evolution Remote	03/13/2018	21.0.0.4-44	Activate Software Package	active0	Velocity Remote	03/13/2018	21.0.0.4-44	Activate Software Package	factory	Evolution Remote	03/13/2018	21.0.0.4-44	Software package is currently active	Partition	Type	Description	Version	Action	active1	Evolution Remote	iDirect Remote Terminal Application	21.0.0.4-44	Activate Software Package	active0	Velocity Remote	iDirect Remote Terminal Application	2.0.0.1-3477	Activate Software Package	factory	Evolution Remote	iDirect Remote Terminal Application	21.0.0.4-44	Software package is currently active								
Software	Package Name	Creation Date	Version	Action																																													
active1	Evolution Remote	03/13/2018	21.0.0.4-44	Activate Software Package																																													
active0	Velocity Remote	03/13/2018	21.0.0.4-44	Activate Software Package																																													
factory	Evolution Remote	03/13/2018	21.0.0.4-44	Software package is currently active																																													
Partition	Type	Description	Version	Action																																													
active1	Evolution Remote	iDirect Remote Terminal Application	21.0.0.4-44	Activate Software Package																																													
active0	Velocity Remote	iDirect Remote Terminal Application	2.0.0.1-3477	Activate Software Package																																													
factory	Evolution Remote	iDirect Remote Terminal Application	21.0.0.4-44	Software package is currently active																																													
<p>Décompresser l'archive .ZIP que vous avez reçu de DSD par email et qui contient 4 fichiers</p> <p>Uploader chacun des 4 fichiers de configuration pour remplacer les fichiers existants</p>	<p>Commissioning Wizard</p> <p>Manage Software Packages</p> <table border="1"><thead><tr><th>Description</th><th>Filename</th><th>Version</th><th>Date</th><th>Size</th><th>Action</th></tr></thead><tbody><tr><td>iDirect manual configuration</td><td>downstream_config.json</td><td></td><td>01/01/1970</td><td>366</td><td>Upload Configuration File Download Configuration File</td></tr><tr><td>iDirect remote configuration</td><td>falcon.opt</td><td></td><td></td><td>0</td><td>Upload Configuration File Download Configuration File</td></tr></tbody></table> <p>Configuration Files</p> <table border="1"><thead><tr><th>Description</th><th>Filename</th><th>Version</th><th>Date</th><th>Size</th><th>Action</th></tr></thead><tbody><tr><td>iDirect remote minimum configuration</td><td>TERMINAL_OPT</td><td>V1.4.0.0</td><td>04/07/2017</td><td>128</td><td>Upload Configuration File Download Configuration File</td></tr><tr><td>iDirect remote Global PKI configuration</td><td>GLOBAL_PKI</td><td>2.0</td><td>09/28/2016</td><td>334</td><td>Upload Configuration File Download Configuration File</td></tr><tr><td>iDirect remote constellation configuration</td><td>CONSTELLATION_OPT</td><td>V1.4.0.0</td><td>04/13/2017</td><td>998</td><td>Upload Configuration File Download Configuration File</td></tr><tr><td>iDirect remote LAN configuration</td><td>TERMINAL_LAN_OPT</td><td>V1.4.0.0</td><td>01/31/2017</td><td>1024</td><td>Upload Configuration File Download Configuration File</td></tr></tbody></table>	Description	Filename	Version	Date	Size	Action	iDirect manual configuration	downstream_config.json		01/01/1970	366	Upload Configuration File Download Configuration File	iDirect remote configuration	falcon.opt			0	Upload Configuration File Download Configuration File	Description	Filename	Version	Date	Size	Action	iDirect remote minimum configuration	TERMINAL_OPT	V1.4.0.0	04/07/2017	128	Upload Configuration File Download Configuration File	iDirect remote Global PKI configuration	GLOBAL_PKI	2.0	09/28/2016	334	Upload Configuration File Download Configuration File	iDirect remote constellation configuration	CONSTELLATION_OPT	V1.4.0.0	04/13/2017	998	Upload Configuration File Download Configuration File	iDirect remote LAN configuration	TERMINAL_LAN_OPT	V1.4.0.0	01/31/2017	1024	Upload Configuration File Download Configuration File
Description	Filename	Version	Date	Size	Action																																												
iDirect manual configuration	downstream_config.json		01/01/1970	366	Upload Configuration File Download Configuration File																																												
iDirect remote configuration	falcon.opt			0	Upload Configuration File Download Configuration File																																												
Description	Filename	Version	Date	Size	Action																																												
iDirect remote minimum configuration	TERMINAL_OPT	V1.4.0.0	04/07/2017	128	Upload Configuration File Download Configuration File																																												
iDirect remote Global PKI configuration	GLOBAL_PKI	2.0	09/28/2016	334	Upload Configuration File Download Configuration File																																												
iDirect remote constellation configuration	CONSTELLATION_OPT	V1.4.0.0	04/13/2017	998	Upload Configuration File Download Configuration File																																												
iDirect remote LAN configuration	TERMINAL_LAN_OPT	V1.4.0.0	01/31/2017	1024	Upload Configuration File Download Configuration File																																												
<p>Entrer les informations du satellite que vous devez pointer ex: IS-19 @ 160 E IS-33 @ 60° East IS-37 @ 18° West</p> <p>Sélectionner "Save remote location and continue"</p>	<p>Commissioning Wizard</p> <p>Coarse antenna pointing</p> <p>Please adjust the values on the left in order to calculate the coarse antenna pointing on the right.</p> <p>Remote Position</p> <table border="1"><tr><td>Remote Latitude</td><td>41.5216</td><td>° (0 - 90)</td></tr><tr><td>Remote Latitude Direction</td><td>North</td><td></td></tr><tr><td>Remote Longitude</td><td></td><td>° (0 - 180)</td></tr><tr><td>Remote Longitude Direction</td><td>East</td><td></td></tr></table> <p>Calculated coarse antenna pointing</p> <table border="1"><tr><td>Elevation Actual</td><td>5.2 degrees (Actual = True - Offset)</td></tr><tr><td>Azimuth True</td><td>102.7 ° (Geographic north = 0°)</td></tr><tr><td>Polarization Offset</td><td>-46.9 ° (Polarization Angle Sense)</td></tr><tr><td>Elevation True</td><td>5.2 ° (Horizontal = 0° Straight up = +90°)</td></tr></table> <p>Antenna</p> <table border="1"><tr><td>Elevation Offset</td><td>0.0000</td><td>° (0 - 90)</td></tr></table> <p>Satellite Position</p> <table border="1"><tr><td>Satellite Longitude</td><td>0.0000</td><td>° (0 - 180)</td></tr><tr><td>Satellite Longitude Direction</td><td>East</td><td></td></tr></table> <p>Save remote location and continue</p>	Remote Latitude	41.5216	° (0 - 90)	Remote Latitude Direction	North		Remote Longitude		° (0 - 180)	Remote Longitude Direction	East		Elevation Actual	5.2 degrees (Actual = True - Offset)	Azimuth True	102.7 ° (Geographic north = 0°)	Polarization Offset	-46.9 ° (Polarization Angle Sense)	Elevation True	5.2 ° (Horizontal = 0° Straight up = +90°)	Elevation Offset	0.0000	° (0 - 90)	Satellite Longitude	0.0000	° (0 - 180)	Satellite Longitude Direction	East																				
Remote Latitude	41.5216	° (0 - 90)																																															
Remote Latitude Direction	North																																																
Remote Longitude		° (0 - 180)																																															
Remote Longitude Direction	East																																																
Elevation Actual	5.2 degrees (Actual = True - Offset)																																																
Azimuth True	102.7 ° (Geographic north = 0°)																																																
Polarization Offset	-46.9 ° (Polarization Angle Sense)																																																
Elevation True	5.2 ° (Horizontal = 0° Straight up = +90°)																																																
Elevation Offset	0.0000	° (0 - 90)																																															
Satellite Longitude	0.0000	° (0 - 180)																																															
Satellite Longitude Direction	East																																																


Liste des fréquences de pointage selon le Beam sur lequel la configuration de votre modem a été établie d'après le nom de ville et/ou les coordonnées GPS que vous avez donné à DSD lors de votre demande d'abonnement

BEAM	Frequency	Symbol Rate	Bitmask	Rx Pol	Tx Pol
FUS-IS33-C4L-K17H.C1	12176.170	24580	4	Horizontal	Vertical
FUS-IS33-C4L-K60H.C1	11517.698	21400	6	Horizontal	Vertical
FUS-IS33-K605V-K61H.C1	11138.300	43330	5	Horizontal	Vertical
FUS-IS37-Ka1L-K11V.C1	12705.713	25790	5	Vertical	Horizontal
FUS-IS37-Ka1L-K12V.C1	11489.005	43080	5	Vertical	Horizontal
FUS-IS37-Ka1L-K16H.C1	11670.021	14820	5	Horizontal	Vertical
FUS-IS37-Ka1L-K17H.C1	12597.639	32250	5	Horizontal	Vertical
FUS-IS37-Ka1L-K22V.C1	11151.800	9650	5	Vertical	Horizontal
FUS-IS37-Ka1L-K23H.C1	11170.317	18330	6	Horizontal	Vertical

A jour en date du 28 juillet 2023


#### IS-37e:

Beams: K11, K12, K16, K17, K22, K23



#### IS-33e:

Beams: K17, K60, K61



Recopier les informations envoyées par DSD:

- RF Frequency
- Mhz
- Modulation-
- Symbol rate-
- Rolloff-
- Receive Polarization-
- Transmit Polarization-
- Vous devez entrer "0" pour la « Latitude Variance » et aussi pour la « Polarization Skew » (c'est un bug iDirect)

Sélectionner "Continue and position antenna"

Maintenant vous pouvez pointer l'antenne vers le satellite, vous avez fini avec la configuration:  
À la fin du pointage vous avez:

- Demod Lock Status: Locked
- Antenna Status: Functional, May Transmit

Enfin:  
Sélectionner "Stop Antenna Pointing"

The search for a satellite is currently in progress

Demod Lock Status: Locked  
Antenna Status: Functional, May Transmit

Stop Antenna Pointing      Continue

**Important** : À la fin du pointage il faut attendre 1 minute que le NET devienne vert fixe ou clignotant

Une fois que le Net est vert alors Sélectionner "Continue"

1. Point the antenna to clear sky  
2. Point until locked onto the downstream carrier (current step)

Voltage



10:05:14      10:05:16      10:05:18      10:05:20      10:05

Stop Antenna Pointing      Use PWM signal:

Volts DC	Antenna Status
0.0 - 0.1	Not in Pointing mode, hardware problem, or off satellite
0.2 - 8.2	Detecting RF energy, but not locked on the downstream carrier



## Guide de configuration et d'activation d'un modem iDirect IQ

Sélectionner "Continue" (page inutile)	
Select "Skip" (page inutile)	

### Mesure du point de compression P1dB

Appeler DSD qui vous fournira la fréquence de test et entrer la fréquence:

- RF Uplink Frequency
- Modulation: CW

Sélectionner "Turn on Signal"

DSD vous guidera et vous dira quelle valeur entrer comme Transmit Power

- Sélectionner "Apply"
- Suivre les instructions jusqu'à la fin de la mesure du point P1dB
- Écrire la valeur du P1dB mesurée par DSD et qui vous sera indiquée

Sélectionner "Turn off signal and complete"

### Mesure de la puissance Max de transmission

DSD vous indique les valeurs à entrer:

- RF Uplink Frequency
- Modulation: BPSK
- Symbol Rate



DSD vous indique quelle valeur de L Band Transmit Power entrer

- Sélectionner "Apply"
- Continuer à suivre les instructions de DSD jusqu'à la fin des mesures
- Ecrire la valeur indiquée par DSD au niveau du Max Transmit

Sélectionner "Turn off signal and complete"



## Guide de configuration et d'activation d'un modem iDirect IQ

	
Une fois que les valeurs du « p1dB Compression Point » et du « Maximum Transmit Power » sont entrées	
Sélectionner "Continue"	
Sélectionner "Exit commissioning mode"	
Sélectionner "Return to dashboard" <b>BRAVO, VOUS AVEZ FINI!</b>	